



757-842-6497  
WWW.JLOSC.COM

**J&L Oil Separator 3.0 Passenger Side  
2011-17 Mustang GT; 2012-13 Boss 302; 2015-20 GT350  
#3011P  
Installation Instructions**

Install video is available on our website  
[www.JLosc.com](http://www.JLosc.com) search 3011P

Remove stock PCV line you are replacing by releasing the plastic tabs and pull the hose off the fittings. Next, install new J&L assembly in its place. Done!

**TO CHECK TANK: HOLD TOP FIRMLY AND UNSCREW BOTTOM**



**ADJUSTMENTS:**

Hoses and fittings can move in shipping, but they are designed to swivel for final adjustment.

All hoses and fittings can rotate 360°. To adjust FORD connector, hold hose and twist connector. To adjust hose, hold fitting or separator and twist on the fitting.

**For BOSS manifold**, raise hose and connect to fitting on manifold. Put wrench on angled fitting and rotate tank until it's level.



To properly clean the filter in the Oil Separator, spray any degreaser or solvent through it and let it air dry. Clean it every 10,000 miles. Thank you for your business. If you have any questions, please e-mail [info@JLosc.com](mailto:info@JLosc.com) or call 757-842-6497. Our hours are Monday-Friday. 8:00am – 4:30pm Eastern Time.

**J&L Oil Separator co. Lifetime Satisfaction Guarantee.** We want you to be a J&L customer for life! Your new J&L product is warranted to be free from defects in materials and workmanship for the life of the *original retail purchaser*, subject to the limitations contained in our warranty found here. [www.JLosc.com/warranty](http://www.JLosc.com/warranty)  
We guarantee workmanship and even a pathway to discounted upgrades for substantially improved items.

**Return Policy:** All returns will be subject to a 10%-25% restocking fee. Please visit [www.JLosc.com](http://www.JLosc.com) for complete return policy.

**Disclaimer:** J&L Oil Separator co. makes no warranties whatsoever, expressed, or implied, oral or written to any purchasers, except the warranty above. J&L Oil Separator co. hereby specifically excludes from any implied warranty of merchantability or implied warranty of incidental, secondary, or consequential damages of any kind whatsoever. All purchasers and users of products manufactured by J&L Oil Separator co. agree to hold harmless and indemnify J&L Oil Separator co. from any and all claims arising from their use. Failure to receive notice of any or the limitations contained in this disclaimer shall not serve to extend liability to J&L Oil Separator co. for any claims arising out of use of its products.